



Antila monobloc

abode

General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the hot valve:

1. Using a 2mm a/f allen key loosen grub screw (C3) in the handle stem (C4).
2. Pull the handle (C4) away from the tap body (B1).
3. Unscrew the decorative valve cover (C2)
4. Unscrew the valve (C1) using a 17mm ring spanner or adjustable wrench.
5. Clean any debris from the chamber in the tap body (B1).
6. Reassemble the tap in the reverse order.

Note. For previous versions of the tap the valve (D5) was a quarter turn compression valve, it has been superseded with a ceramic valve. Also previous versions had a multipart assembled handle, to remove the handle remove the branded dust cap using a small screwdriver then unscrew the valve screw within the handle then follow steps 2-6

To replace the spout o-rings:

1. Loosen grub screw (A9) on the rear of body (B1) using a small flathead screwdriver.
2. Pull the spout (A4) vertically away from the body (B1).
3. Remove the old o-rings (A6 & A7) using a small screwdriver or similar.
4. If worn, remove the white PTFE spacer (A5 & A8).
5. Ensure the inside of the body (B1) and the spout base is clean of dirt and grit with a soft wet cloth.
6. If required locate the new white PTFE spacer (A5 & A8).
7. Carefully locate the new O-rings (A6 & A7) onto the spout base (A4).
8. Grease the O-rings (A6 & A7) thoroughly with silicone or alternative similar grease.
9. Reassemble the tap in the reverse order.