



COMPATIBLE VALVE/CARTRIDGE CHANGE GUIDE


For use with the following Perrin & Rowe kitchen tap

Oberon



IMPORTANT! BEFORE YOU BEGIN

Replacing the valve/cartridge of a Perrin & Rowe tap is a straightforward procedure for any competent handy person. However, should you have any doubts about your ability to tackle the task, we suggest you engage a suitably qualified professional. You can also gain hints and tips about replacing a valve by watching our installation movies at TapSparesUK.com.



ESSENTIAL TOOLS

17mm ring spanner or suitable adjustable spanner

VALVE/CARTRIDGE CHANGE PROCEDURE

1. Turn off the water supply to the tap
2. Unscrew and remove the shroud (A) that secures the handle. A rubber glove will help grip if the shroud is tight.
3. Remove plastic vernier (B). It will either remain at the end of the old valve or stay inside the handle (new verniers are supplied with your new valves).
4. Unscrew the old valve (C) using a 17mm or adjustable spanner. Bear in mind that it might take some initial force to free the valve if it has been there for sometime.
5. The valves are identifiable by the colour of the silicone insert (D)—you should have a red one and a blue one.
6. Screw each valve into the correct position and tighten firmly.
7. Check the spindle of each valve is in the closed position. Then slide the new vernier onto the splined valve spindle. Align the handle as close to vertical as you can manage, but without clipping it on fully. If the handle is not vertical, remove it carefully while keeping the vernier in place. Slide off the vernier and rotate it 1 or 2 notches. Try the handle again. Repeat this operation until you are satisfied with the lever alignment and then screw the shroud back into place.
8. Turn on the water supply back on and check for leaks.